


**NOTE:** Prior work shows that, except for T8 (truss #8, east end of pier), which has the broken top chord, most of the truss repairs consist of one or the other of two tasks: 1) collar ties (five, 5X), or 2) "just posts" (nine, 9X).

Reusable 4x6 bracing (light blue), needs connections, clamps, wedges, jacks, slings and rigging, that allow routine installation and removal in a single day. A collar-tie crew and a post crew repeat the same jobs, moving and reusing the bracing.



**Task 1 - collar-tie - 5X**  
**replace collar-tie, post, knee bracing, two post-to-post beams**

**Objectives:** replace T3 south collar tie, T3 south post, T3 south knee bracing, two south post-to-post beams (yellow) that connect T2, T3 and T4


**Task 2 - post - 9X**  
**replace post, knee bracing, two post-to-post beams**

**Objectives:** replace T7 south post, T7 south knee bracing, two south post-to-post beams (yellow) that connect T6, T7 and T8

Temporary collar-ties can be fixed length and permanently attached to posts? They must be strapped (in tension) to the bottom longitudinal beam in center.

Adjustable blocks clamp to trusses (or fixed blocks and shims to fill gaps?)

whole beam strapped up to each truss (strapping not shown)



bracing alone

Double posts leave maximum room to work.

**Objectives:** replace T3 south collar tie, T3 south post, T3 south knee bracing, two south post-to-post beams (yellow) that connect T2, T3 and T4

# Task 1: collar-tie, 5X

## Hanalei Pier Repair Project

Rotary Club of Hanalei Bay  
Hanalei, Kauai, Hawaii


Mar 23, 2011

by Joseph Oster

[www.wingo.com/SketchUp](http://www.wingo.com/SketchUp)

wingo.com  
web site design

808-826-5316



**Objectives:** replace T7 south post, T7 south knee bracing, two post-to-post beams (yellow) that connect T6, T7 and T8

## Task 2: post, 9X

### Hanalei Pier Repair Project

Rotary Club of Hanalei Bay  
Hanalei, Kauai, Hawaii

Mar 23, 2011

wingo.com  
web site design

by Joseph Oster  
www.wingo.com/SketchUp  
808-826-5316